




Craftsman
MARINE



SPARE PARTS

CATALOGUE

cm 4.33 / cm 4.42

CRAFTED WITH CRAFTSMAN MARINE

PROPULSION

DISCLAIMER

The specifications and the descriptions in this spareparts book were correct at the time of going to press. However, Craftsman Marine is continuously striving after the improvement of its products and therefore reserves the right to modify – at all times and without prior notification - product specifications and instruction manuals.

1.0 MARINISATION PARTS

1.1 SPARES SET	PAGE 4
1.2 AIR INTAKE	PAGE 6
1.3 AUXILIARY FUELPUMP & FILTER	PAGE 8
1.4 FLYWHEEL HOUSING	PAGE 10
1.5 ENGINE SUPPORT	PAGE 12
1.6 HEAT EXCHANGER	PAGE 14
1.7 KEELCOOLER MANIFOLD	PAGE 16
1.8 THERMOSTAT	PAGE 18
1.9 HOSES	PAGE 20
1.10 RAW WATER PUMP	PAGE 22

2.0 MITSUBISHI PARTS

2.1 CIRCULATION PUMP & THERMOSTAT	PAGE 24
2.2 CRANKCASE ASSY	PAGE 26
2.3 CRANKCASE	PAGE 28
2.4 OIL PAN & OIL PUMP	PAGE 30
2.5 CILINDER HEAD	PAGE 32
2.6 CRANKSHAFT & FLYWHEEL	PAGE 34
2.7 ROCKER COVER & CAMSHAFT	PAGE 36
2.8 TIMING GEAR & CASE	PAGE 38
2.9 GOVERNOR	PAGE 40
2.10 FUEL SYSTEM	PAGE 42
2.11 FUEL INJECTION PUMP DRIVE	PAGE 44
2.12 INJECTION PUMP	PAGE 46
2.13 NOZZLE & NOZZLE HOLDER	PAGE 48
2.14 GASKET KIT	PAGE 50

3.0 ELECTRONICS

3.1 STARTER MOTOR & ALTERNATOR	PAGE 52
3.2 TERMINAL BOX	PAGE 54
3.3 SENSORS	PAGE 56
3.4 INSTRUMENT PANEL	PAGE 58
3.5 INSTRUMENT PANEL	PAGE 60

SPARE PARTS


CM4.33 / CM4.42



1.1 SPARES SET

[illegible]

1.1 SPARES SET



Craftsman
MARINE


MARINISATION PARTS

MITSUBISHI PARTS

ELECTRONICS

6 CRAFTED WITH CRAFTSMAN MARINE

1.2 AIR INTAKE



MARINISATION PARTS

MITSUBISHI PARTS

ELECTRONICS


[illegible]

1.3 AUXILIARY FUELPUMP & FILTER

MARINISATION PARTS

MITSUBISHI PARTS

ELECTRONICS



Craftsman
MARINE


MARINISATION PARTS

mitsubishi parts

ELECTRONICS

10 CRAFTED WITH CRAFTSMAN MARINE

1.4 FLYWHEEL HOUSING



SPARE PARTS


CM4.33 / CM4.42

Craftsman
MARINE

1.5 ENGINE SUPPORT

[illegible]

1.5 ENGINE SUPPORT



SPARE PARTS


cm4.33 / cm4.42



1.6 HEAT EXCHANGER

[illegible]

1.6 HEAT EXCHANGER



CM4.33 / CM4.42



1.7 KEELCOOLER MANIFOLD


[illegible]

1.7 KEELCOOLER MANIFOLD

MARINISATION PARTS

MITSUBISHI PARTS

ELECTRONICS




CM4.33 / CM4.42



1.8 THERMOSTAT

[illegible]

1.8 THERMOSTAT



SPARE PARTS


CM4.33 / CM4.42



1.9 HOSES

[illegible]

1.9 HOSES




CM4.33 / CM4.42



1.10 RAW WATER PUMP

[illegible]


1.10 RAW WATER PUMP



2.1 CIRCULATION PUMP & THERMOSTAT

[illegible]

2.1 CIRCULATION PUMP & THERMOSTAT



SPARE PARTS


CM4.33 / CM4.42



2.2 CRANKCASE ASSY

[illegible]

2.2 CRANKCASE ASSY



SPARE PARTS


CM4.33 / CM4.42



2.3 CRANKCASE

[illegible]

2.3 CRANKCASE



SPARE PARTS


CM4.33 / CM4.42

Craftsman
MARINE

2.4 OIL PAN & OIL PUMP

[illegible]

2.4 OIL PAN & OIL PUMP



Craftsman
MARINE



MARINISATION PARTS

MITSUBISHI PARTS

ELECTRONICS

[illegible]

2.5 CILINDER HEAD




CM4.33 / CM4.42

2.6 CRANKSHAFT & FLYWHEEL

[illegible]

2.6 CRANKSHAFT & FLYWHEEL




CM4.33 / CM4.42



2.7 ROCKER COVER & CAMSHAFT

[illegible]

2.7 ROCKER COVER & CAMSHAFT



SPARE PARTS


CM4.33 / CM4.42



2.8 TIMING GEAR & CASE

[illegible]

2.8 TIMING GEAR & CASE



SPARE PARTS


cm4.33 / cm4.42



2.9 GOVERNOR

[illegible]

2.9 GOVERNOR




CM4.33 / CM4.42



2.10 FUEL SYSTEM

[illegible]


2.10 FUEL SYSTEM



2.11 FUEL INJECTION PUMP DRIVE

[illegible]

2.11 FUEL INJECTION PUMP DRIVE



SPARE PARTS


CM4.33 / CM4.42



2.12 INJECTION PUMP

[illegible]


2.12 INJECTION PUMP



2.13 NOZZLE & NOZZLE HOLDER

[illegible]

2.13 NOZZLE & NOZZLE HOLDER



Craftsman
MARINE


MARINISATION PARTS

MITSUBISHI PARTS

ELECTRONICS

50 CRAFTED WITH CRAFTSMAN MARINE


2.14 GASKET KIT



3.1 STARTER MOTOR & ALTERNATOR

[illegible]

3.1 STARTER MOTOR & ALTERNATOR




CM4.33 / CM4.42



3.2 TERMINAL BOX

[illegible]

3.2 TERMINAL BOX




CM4.33 / CM4.42



3.3 SENSORS

[illegible]



3.3 SENSORS



3.4 INSTRUMENT PANEL

[illegible]



3.4 INSTRUMENT PANEL



3.5 INSTRUMENT PANEL

[illegible]

3.5 INSTRUMENT PANEL






ZD-010-015.2.1.01.11

info@craftsmanmarine.com
www.craftsmanmarine.com

Printed in the Netherlands



CRAFTED WITH CRAFTSMAN MARINE